

1/14




FIG. 1

2/14




FIG. 2

3/14




FIG. 3




FIG. 4

10/52'313

4/14




FIG. 5




FIG. 6

5/14




FIG. 7

6/14




FIG. 8

7/14




FIG. 9

20/520700

8/14






FIG. 10




9/14



(a)



(b)



(c)

FIG. 11

10/14




FIG. 12

11/14




FIG. 13

12/14

CRT display screen example

print paper	print mode	print resolution (dpi)	ON/OFF setting check boxes
normal paper	text characters	360 × 360	<input type="radio"/> ON <input checked="" type="radio"/> OFF
	graph	720 × 720	<input checked="" type="radio"/> ON <input type="radio"/> OFF
	photograph	720 × 720	<input checked="" type="radio"/> ON <input type="radio"/> OFF
matte paper	text characters	360 × 360	<input type="radio"/> ON <input checked="" type="radio"/> OFF
	graph	720 × 720	<input checked="" type="radio"/> ON <input type="radio"/> OFF
	photograph	1440 × 720	<input checked="" type="radio"/> ON <input type="radio"/> OFF
photograph paper	photograph	1440 × 720	<input checked="" type="radio"/> ON <input type="radio"/> OFF
OHP paper	text characters	360 × 360	<input type="radio"/> ON <input checked="" type="radio"/> OFF
	graph	720 × 720	<input checked="" type="radio"/> ON <input type="radio"/> OFF

FIG. 14

data table stored in a memory of computer 90

print paper	print mode	ON/OFF setting check boxes
normal paper	text characters	OFF
	graph	ON
	photograph	ON
matte paper	text characters	OFF
	graph	ON
	photograph	ON
photograph paper	photograph	ON
OHP paper	text characters	OFF
	graph	ON

FIG. 15

13/14




FIG. 16

14/14




FIG. 17